

# NJORD® GO

## GETTING STARTED

CTEK

### CONNECT



1 Plug NJORD® GO into the supply outlet



2 Connect the NJORD® GO to the vehicle


### CONNECT WITH CTEK APP (OPTIONAL) FOR ADDITIONAL FUNCTIONALITY



1 Download the CTEK App from App Store or Google Play for additional functionality



2 Plug NJORD® GO into the supply outlet



3 Connect the NJORD® GO to the CTEK App within 2 minutes



4 Connect the NJORD® GO to the vehicle

### CHARGE



NJORD® GO is powered on, waiting to charge



Vehicle is charging



Vehicle is charged / vehicle has paused charging




NJORD® GO requires authorisation from CTEK App or charging session was paused via CTEK App

### OTHER INFO



Bluetooth® pairing mode (flashing) or CTEK App is connected via Bluetooth® (single flash)



Remote connection active (single flash)



NJORD® GO is downloading an update (solid) or NJORD® GO is installing an update (flashing)

### ERRORS



ERROR: Charging is not available (contact CTEK)



ERROR: self-check fail (restart NJORD® GO, if persists, contact CTEK)



ERROR: Ground fault detected (restart NJORD® GO, if persists, contact CTEK)



ERROR: Temperature limit reached (leave to cool down)

Discover more about NJORD® GO



Users can contact CTEK via CTEK App or on support.ctek.com